

## VICTORIA PLUS SILENT VS CONTROL PANEL MANUAL

---



UK  
CA



**ASTRALPOOL** 

VICTORIA PLUS SILENT VS

English - HMI VICTORIA PLUS SILENT VS CONTROL PANEL INSTRUCTION MANUAL .....	3
---	---

Français - PANNEAU DE CONTRÔLE HMI VICTORIA PLUS SILENT VS MANUEL D'INSTRUCTIONS.....	31
--	----

Español - PANEL DE CONTROL HMI VICTORIA PLUS SILENT VS MANUAL DE INSTRUCCIONES.....	59
--	----

Italiano - PANNELLO DI CONTROLLO HMI VICTORIA PLUS SILENT VS MANUALE DI ISTRUZIONI.....	87
--	----


Deutsch - HMI-BEDIENFELD VICTORIA PLUS SILENT VS BEDIENUNGSANLEITUNG.....	115
--	-----

Português - PAINEL DE CONTROLO HMI DA VICTORIA PLUS SILENT VS MANUAL DE INSTRUÇÕES .....	143
---	-----

Ελληνικά - ΠΙΝΑΚΑΣ ΕΛΕΓΧΟΥ HMI VICTORIA PLUS SILENT VS Εγχειρίδιο .....	171
--	-----

عربي - لوحة التحكم HMI VICTORIA PLUS SILENT VS كتيب التعليمات .....	199
--	-----

# CONTROL PANEL



## HOW TO USE THE CONTROL PANEL

The **Victoria Plus Silent VS** variable speed pump has a **control panel** for switching the pump on and off, and for adjusting and displaying the pump's settings and configuration.

### CONTROL KEYS:

- ① **On/Off:** Press the button to switch the pump on or off. The pump will always start in the same mode and with the same configuration as when it was last switched off.  
When the off button is pressed, the message "**OFF**" will be displayed on the screen for 2 minutes.
- ② **Auto Mode:** Press the button so that the pump connects and disconnects in **AUTO Mode** at the setpoint **Times and Speeds**.
- ③ **Settings:** Press the button to enter the **Settings Menu**. The **Settings Menu** can be accessed both when the pump is on or off, provided it is plugged in.
- ④ **Exit:** In the **Settings Menu**, press the button to exit without saving your changes. Every press of the button will go back one step in the **Settings Menu**.
- ⑤ **Enter:** In the **Settings Menu**, press the button to enter the option selected or to accept/save changes made to the settings.
- ⑥ **Setpoint Mode. Low Speed:** Press the button so that the pump runs or starts up at **Low Speed** (by default, 1.400 rpm).
- ⑦ **Setpoint Mode. Medium speed:** Press the button so that the pump runs or starts up at **Medium Speed** (by default, 2.100 rpm).
- ⑧ **Setpoint Mode. High speed:** Press the button so that the pump runs or starts up at **High Speed** (by default, 2.750 rpm).
- ⑨ **Setpoint Mode. Turbo Speed:** Press the button so that the pump runs or starts up in **Manual Mode** at **Turbo Speed**. This mode is used for self-priming, fast cleaning, etc. (by default 2.850 rpm). The **Manual Mode** at **Turbo Speed** lasts a set time that once over will automatically go into **Manual Mode** at **High Speed**.
- ⑩ **Arrow buttons:** Browsing, selection and settings buttons.
  - Up arrow:** In the **Settings Menu**, this arrow increases the value of the setting selected or goes on to the next option. If you wish to increase the value selected without stopping, keep the button pressed down for more than 3 seconds and release it when the desired value has been reached.  
This arrow also starts the pump in **Manual Mode** when it is in **Standby Mode** or in **Auto Mode** and increases the running speed.
  - Down arrow:** In the **Settings Menu**, this arrow decreases the value of the setting selected or goes back to the previous option. If you wish to decrease the value selected without stopping, keep the button pressed down for more than 3 seconds and release it when the desired value has been reached.  
This arrow also starts the pump in **Manual Mode** when it is in **Standby Mode** or in **Auto Mode** and decreases the running speed.
  - Left arrow:** This arrow scrolls through the options on the left of the **Settings Menu** or goes forward through the options in the **Settings Menu**.
  - Right arrow:** This arrow scrolls through the options on the right of the **Settings Menu** or goes backward through the options in the **Settings Menu**.

# 1. PUMP START-UP

Ensure that the pump is plugged in. When plugged in for the first time, it goes into **STANDBY Mode** and the message "OFF" is displayed on the screen for 2 minutes.

Every time the pump is unplugged and then plugged back in, the pump will start in the same mode and with the same configuration as the last time before it was unplugged.

In **STANDBY Mode**, press button ① (On/off) to switch the pump on. The first time it is started up, **AUTO Mode** will be displayed on the screen. As there is no initial auto-configuration, the pump will not start until the **AUTO Mode** is configured or the **MANUAL Mode** used.

When the pump is on in any mode, pressing button ① (On/off) will put the pump into **STANDBY Mode**.


In **STANDBY Mode**, the pump will neither run nor will the auto-configuration in **AUTO Mode** be enabled.

If started up on successive occasions, the pump will switch on in the same mode (**MANUAL** or **AUTO**) and with the same configuration as the last time it was switch off, even if unplugged from the mains.



If there is a power cut or if the pump is unplugged while it is running, it will go back to the same operating mode once the power supply is back.

## SEQUENCE OF THE FIRST START-UP




## 2. PUMP OPERATING MODES

The pump can work in **MANUAL Mode** or **AUTO Mode**. To stop it from running in **MANUAL** or **AUTO Mode** put it back in **STANDBY Mode**, by pressing button ① (On/Off).

In **STANDBY Mode**, the pump will neither run nor will the auto-configuration in **AUTO Mode** be enabled.

Whenever the pump is started up (in **MANUAL** or **AUTO Mode**) from the **STANDBY Mode**, it will self-prime for 30 seconds at a speed of 2.850 rpm by default before starting up again. The default self-priming time and speed can be adjusted, and can be disabled from the **EXPERT** settings menu (see Section 2.3.9). While it is self-priming, the speed reading of the mode selected will flash on and off until the process has been completed.

### START-UP IN MANUAL MODE. SELF-PRIMING:




### 2.1 MANUAL MODE

In **MANUAL Mode**, the pump can be manually switch on or off and the operating speed adjusted to the desired setting.

To stop the pump from running in **MANUAL Mode**, press button ① (On/Off) so that it goes back into **STANDBY Mode**.

In **MANUAL Mode**, a **Setpoint Speed** can be selected (see Section 2.1.1) or the speed can be set manually (see Section 2.1.2).

### MANUAL MODE SCREEN:




## 2.1.1 MANUAL MODE WITH SETPOINT SPEED

The pump has 4 **Setpoint Speeds** in **MANUAL Mode**: Low, Medium, High and Turbo.

**Turbo Speed** is normally used for fast cleaning and is pre-set by the manufacturer to last 10 minutes. Once this time is over, the pump will automatically run in **MANUAL Mode** at **High Speed**. The speed and duration of the **Turbo Speed** cannot be changed for safety reasons.

The **Low, Medium and High** setpoint operating speeds can be configured from the **SETPOINT** option on the **Settings Menu** (see Section 2.1.5) or from the **EXPERT MODE** option in the **Settings Menu** (see Section 2.1.9).

Use the following sequences for running the pump in **MANUAL Mode** with a **Setpoint Speed**:




The **Setpoint Speed** can be changed by pressing the **Up Arrow** to increase it and the **Down Arrow** to decrease it. By pressing it for a short interval, it increases by 25 rpm and by pressing it for long intervals (> 3s) it increases non-stop until the button is released.

When the **Setpoint Speed** is increased or decreased, the corresponding icon disappears and it goes into **MANUAL Mode**.

The speeds range from a minimum of 1.000 rpm to a maximum of 2.750 rpm. When the top or bottom rpm speed is reached in **MANUAL Mode**, the pump lets off a prolonged beeping sound.


### EXAMPLE OF THE VARIATION IN THE MEDIUM SETPOINT SPEED IN MANUAL MODE:



## 2.1.2 OPERATING MODE WITH MANUAL SPEED SETTING


The pump's operating speed is started up and adjusted by the user manually.

USE THE FOLLOWING SEQUENCE FOR SETTING THE SPEED IN MANUAL MODE.



## 2.2 AUTO MODE

In **AUTO Mode**, the pump automatically runs a weekly programmable timer set by the user for which the desired **Setpoint Speeds** must be configured.

 To run in **AUTO Mode**, it is essential to configure the **Day** and **Time** under the **CLOCK** and **DAY** options in the **Settings Menu** (see Sections 2.1.1 **CLOCK** and 2.1.2 **DAY**).

The timer will be programmed based on each pool (energy savings, total water volume, etc.) and the times it is normally used.

To run the pump in **AUTO Mode**, press button ② (**AUTO**). The screen will show the timer settings for the current day of the week.

To cancel the **AUTO Mode**, either press button ① (**On/Off**) to enable the **STANDBY Mode** or to put the pump into **Manual Mode**.


Whenever the pump is started up in **MANUAL Mode**, it will self-prime for 30 seconds at a speed of 2.850 rpm by default. **The default self-priming time and speed can be adjusted, and can also be disabled from the EXPERT Mode** in the **Settings Menu** (see Section 2.3.9). While it is self-priming, the speed reading will flash on and off until the process has been completed.

If the pump is running in **MANUAL Mode** and the **AUTO Mode** is enabled, it will work according to the automatic timer settings.

To display and configure the timer for the whole week, go to the **TIMER** option in the **Settings Menu** (Section 2.3.8).

If you wish to configure the **Setpoint Speeds**, go to the **SETPOINT** option in the **Settings Menu** (Section 2.3.5).

### ENABLING AUTO MODE:




## 2.3 SETTINGS MENU

Press button **③** to access the **Settings Menu**. You can access the **Settings Menu** from any Operating Mode (**STANDBY Mode**, **MANUAL Mode** or **AUTO Mode**), both when the pump is on and off.

To browse through the **Settings Menu** options, use the **Left and Right Arrow Buttons** (**⑩**). The option on the **Settings Menu** selected will flash. Press button **⑤** (**Enter**) to configure the option selected in the **Settings Menu**. Once in the option under the **Settings Menu**, only the option selected will be displayed on the options bar.

### ON ACCESSING THE CONFIGURATION OF THE OPTION SELECTED IN THE SETTINGS MENU:



Press the **Left and Right Arrow Buttons** (**⑩**) to browse through the settings and the **Up and Down Arrow Buttons** (**⑩**) to modify them.




Press button **⑤** (**Enter**) to accept/save the changes made and go on to the next setting or end the set-up by going back to the **Settings Menu**.



Under the configuration of the setting selected, press button **④** (**Exit**) to go back to the **Settings Menu** without saving the changes made. Press button **④** (**Exit**) again if you wish to exit the **Settings Menu** in order to go back to the **Operating Modes**.

### EXAMPLE OF AN OPTION SELECTED IN THE SETTINGS MENU:





## SETTINGS MENU

### 2.3.1 CLOCK

Time display and settings

### 2.3.2 DAY

Day of the week display and settings

### 2.3.3 UNITS

Pump mode settings display.

**Rpm:** Pump rotational speed

**%:** Pump operating load

**W:** Power consumption

**kWh:** Overall power consumption

### 2.3.4 SETPOINT UNITS

Speed Setpoint Unit display and configuration.

**Rpm:** Pump rotational speed

**%:** Pump operating load

### 2.3.5 SETPOINT

Setpoint display and configuration.

Configures the  
operating speed:

**Low.** Low **rpm** or **%** operating capacity of the pump

**Medium.** Medium **rpm** or **%** operating capacity of the pump

**High.** High **rpm** or **%** operating capacity of the pump

### 2.3.6 SAVINGS DISPLAY

Configures the unit displayed in power savings

**€/WEEK:** Weekly power savings in euros

**€/YEAR:** Annual power savings in euros

**\$/WEEK:** Weekly power savings in dollars

**\$/YEAR:** Annual power savings in dollars

### 2.3.7 SAVINGS SETTING

Configures the settings for calculating power savings.

**h/DAY SINGLE SPEED:** The pump's daily operating time in hours

**€/kWh—\$/kWh:** Cost of a kWh in euros or dollars

### 2.3.8 TIMER


AUTO Mode display and configuration.

### 2.3.9 EXPERT MODE

Advanced configuration.


### 2.3.1 CLOCK. SETTING THE TIME

1. Select the **CLOCK** option in the **Settings Menu** to display the time.
2. Enter the **CLOCK** option in the **Settings Menu** to set the time. The digit selected will flash.
3. Use the **Left and Right (10) Arrow Buttons** to move from one digit to another.
4. Press the **Up and Down (10) Arrow Buttons** to increase or decrease the value of the digit selected.
5. Press button **(5) (Enter)** to confirm the time set. Once confirmed, it will go back to the options under the **Settings Menu**.




## 2.3.2 DAY. DAY OF THE WEEK

1. Select the **DAY** option in the **Settings Menu** to display the day of the week.
2. Enter the **DAY** option in the **Settings Menu** to set the day of the week.
3. Use the **Up and Down Arrow Buttons** (10) to change the day of the week.
4. Press button (5) (Enter) to confirm the day of the week selected. Once confirmed, it will go back to the options in the **Settings Menu**.




## 2.3.3 UNITS

1. Select the **UNITS** option in the **Settings Menu** to display the reading of the unit selected.
2. Enter **UNITS** in the **Settings Menu** to display the readings of the pump's operating settings. The setting selected will flash.
3. Use the **Up and Down Arrow Buttons** (⑩) to display the various settings:
  - **Rpm**: Displays the motor's rotational speed in revolutions per minute.
  - **%**: Displays the pump's operating capacity in % (35% = minimum load — 100% = maximum load).
  - **W**: Displays the motor's power consumption in watts.
  - **kWh**: Displays the pump's overall power consumption in kilowatt hours. To reset the consumption meter, keep button ⑤ (Enter) pressed down for more than 5 seconds.
  - **Hz**: Displays the electrical frequency fed to the motor in hertz.
4. Press button ⑤ (Enter) to select the reading to be displayed. Once confirmed, it will go back to the options under the **Settings Menu**.



## 2.3.4 SETPOINT UNITS. CONFIGURATION OF SETPOINT UNITS

1. Select the **SETPOINT UNITS** option in the **Settings Menu** to display one of them.
2. Enter **SETPOINT UNITS** in the **Settings Menu** to modify the **Setpoint Unit**. The unit selected will flash.
3. Use the **Up and Down Arrow Buttons** (10) to modify the unit. Select from among the the following units:
  - **Rpm**: Displays the motor's rotational speed in revolutions per minute.
  - **%**: Displays the pump's operating capacity in % (100% = full load) depending on the motor's rotational speed: (a full load is equal to the top working speed at 2.750 rpm).
4. Press button (5) (Enter) to confirm the unit's value for **Setpoint Operations**. Once confirmed, it will go back to the options under the **Settings Menu**.




## 2.3.5 SETPOINTS. CONFIGURATION OF SETPOINTS


1. Enter the **SETPOINT** option in the **Settings Menu** to display/modify the values assigned to the **Setpoint Units**. The **Setpoint Unit** selected will flash.
2. Use the **Up and Down Arrow Buttons** (10) to increase or decrease the value assigned to the **Setpoint Unit**. There are 3 **Setpoint Unit** modes that can be configured:
  - **Low Setpoint:** Low rpm or % operating capacity of the pump (depending on the unit configured. See Section 2.3.4, **SETPOINT UNITS**). Minimum value.
  - **Medium Setpoint:** Medium rpm or % operating capacity of the pump (depending on the unit configured. See Section 2.3.4, **SETPOINT UNITS**). Intermediate value.
  - **High Setpoint:** High rpm or % operating capacity of the pump (depending on the unit configured. See Section 2.3.4, **SETPOINT UNITS**). Maximum value.

The operating mode speed will be incremental starting from the **Low Setpoint** up to the **High Setpoint**, in other words, the **Medium Setpoint** value cannot be higher than the **High Setpoint** value or lower than the **Low Setpoint** value. The following condition must therefore always be fulfilled:

**High Setpoint Value ≥ Medium Setpoint Value ≥ Low Setpoint Value.**

3. Press button (5) (Enter) to confirm the value assigned to the **Setpoint Unit**. Once confirmed, it will go on to the next **Setpoint Unit**. Once the last **Setpoint Unit** value has been entered, it will return to the option in the **Settings Menu**.






## 2.3.6 SAVINGS DISPLAY. DISPLAY OF POWER SAVINGS

1. Select the **SAVINGS DISPLAY** option in the **Settings Menu** to display the power savings reading.
2. Enter **SAVINGS DISPLAY** in the **Settings Menu** to modify the power savings unit displayed. The unit configured will flash.
3. Use the **Up and Down Arrow Buttons** (10) to modify the unit displayed. Select from among the the following units:
  - **€/WEEK:** Weekly power savings in euros.
  - **€/YEAR:** Annual power savings in euros.
  - **\$/WEEK:** Weekly power savings in dollars.
  - **\$/YEAR:** Annual power savings in dollars.
  - Do not display Power Savings. The unit will not be displayed on the screen.
4. Press button (5) (Enter) to confirm the selection of the power savings unit to be displayed. Once confirmed, it will go back to the options under the **Settings Menu**.



In order to correctly display the power savings, first set the power savings under the **SAVINGS SETTINGS** option in the **Settings Menu** (see Section 2.3.7).

The reading of the Power Savings displayed under the **SAVINGS DISPLAY** option is calculated based on the setting entered under the option **SAVINGS SETTING** in the **Settings Menu** (see Section 2.3.7), and shows the savings made using a variable speed pump in comparison with a single speed pump.



## 2.3.7 SAVINGS SETTING. SETTING POWER SAVINGS


1. Enter the **SAVINGS SETTING** option in the **Settings Menu** to adjust the settings for calculating power savings. The digit of the value of the first setting, h/DAY SINGLE SPEED, will flash.


The power savings reading displayed under the **SAVINGS DISPLAY** in the **Settings Menu** (see Section 2.3.6) is calculated based on the following settings:

- **h/DAY SINGLE SPEED:** The pump's daily operating time in hours.
- **€/kWh—\$/kWh:** Cost of a kWh, in euros or dollars depending on the option selected under **SAVINGS DISPLAY** in the **Settings Menu** (see Section 2.1.6).

2. To configure the pump's daily operating time in hours (**h/DAY SINGLE SPEED**) from the **SAVINGS SETTING** option, press the **Left and Right Arrow Buttons** (⏪ ⏩) to move from one digit to another — the digit selected will flash — and press the **Left and Right Arrow Buttons** (⏪ ⏩) to increase or decrease the digit selected. Once the value of the setting has been set, press button (5) (Enter) to confirm.

Once the first "h/DAY SINGLE SPEED" setting has been confirmed, it will go on to the second setting, i.e., **€/kWh—\$/kWh**. Configure the cost of a kWh (**€/kWh—\$/kWh**) by pressing the **Left and Right Arrow Buttons** (⏪ ⏩) to move from one digit to another and the **Left and Right Arrow Buttons** (⏪ ⏩) to increase or decrease the digit selected. Once the value of the setting has been set, press button (5) (Enter) to confirm. Once confirmed, it will go back to the options under the **Settings Menu**.





## 2.3.8 TIMER. SETTING AUTO MODE

1. Select the **TIMER** option in the **Settings Menu** to display the **AUTO Mode** times set for the current day of the week.
2. Enter the **TIMER** option in the **Settings Menu** to display or adjust the weekday times set for **AUTO Mode**. The day of the week selected will flash.

If you wish to delete all weekly times set in **AUTO Mode**, keep buttons ⑤ (Enter) and ③ (Settings) pressed down at the same time for at least 3 seconds when you enter the **TIMER** option.

To display the weekday times, use the **Up and Down Arrow Buttons** (⑩) to select the **weekday** option to be set. Use the following weekday options:


- **MON:** **AUTO Mode** for **MONDAYS**
- **TUE:** **AUTO Mode** for **TUESDAYS**
- **WED:** **AUTO Mode** for **WEDNESDAYS**
- **THUR:** **AUTO Mode** for **THURSDAYS**

- **FRI:** AUTO Mode for **FRIDAYS**
- **SAT:** AUTO Mode for **SATURDAYS**
- **SUN:** AUTO Mode for **SUNDAYS**
- **MON TUE WED THUR FRI SAT SUN:** AUTO Mode every day of the week from **MONDAY** TO **SUNDAY**.
- **SAT SUN:** AUTO Mode for weekends (**SATURDAYS AND SUNDAYS**).

Press button **(5) (Enter)** to confirm the weekday selection you wish to configure.

3. Press the **Left and Right Arrow Buttons (10)** to move from one time slot to another. The time slot selected will flash. In the time slot selected, press the **Up and Down Arrow Buttons (10)** as many times as necessary for the desired **Setpoint Unit** to be displayed or set the mode by directly pressing button **(6) (7)** or **(8)** of the **Low, Medium or High Setpoint Unit**.

#### CONFIGURATION OPTIONS AVAILABLE FOR THE SELECTION OF THE TIME SLOT IN AUTO MODE.




**Pump Off.** While the time slot selected is flashing, the speed mode changes. On moving from one time slot to another, the assigned speed mode will not be displayed.

4. Press button **(5) (Enter)** to confirm the weekday option selected. Once confirmed, it will go back to the weekday selection option. If required, the next day to be configured can be selected at this point or button **(4) (Exit)** pressed to go back to the options in the **Settings Menu**.



Only press button **(5) (Enter)** button when the weekday selection has been completely finished.


The **Low, Medium and High Setpoints** can be configured from the **SETPOINT** option in the **Settings Menu** (see Section 2.3.5).




## 2.3.9 EXPERT MODE. ADVANCED MENU

1. Enter the **EXPERT Mode** option in the **Settings Menu** to access the advanced menu settings..
2. Browse, select and set the options and settings in the advanced menu by using the Arrow Buttons (**10**).
3. Press button **5** (**Enter**) button to confirm the setting made or press button **4** (**Exit**) button to go back to the options in the **Settings Menu**.

### OPTIONS IN THE ADVANCED SETTINGS MENU:





### 3. HOW TO BLOCK THE CONTROL PANEL


In **STANDBY Mode**, **MANUAL Mode** or **AUTO Mode**, press the **③ Settings** and **⑤ Enter** buttons at the same time for at least 3 seconds to block access to the control panel. Use the same sequence to unblock the control panel.

When the control panel is blocked, only the **CLOCK** and **DAY** options in the **Settings Menu** will be enabled for display and to change the settings.



Block the **Control Panel** in **AUTO Mode** so that the pump starts up the weekly cycle. When the **Control Panel** is blocked, the pump will only work in **AUTO Mode** if a cycle has been programmed. If the **Control Panel** is blocked in **STANDBY Mode**, the pump will not run until it has been unblocked.

#### CONTROL PANEL BLOCKING AND UNBLOCKING SEQUENCES



## 4. CONNECTIVITY PRIORITIES

Direct commands on the Control Panel take priority over commands from the remote control via Modbus. For safety, while direct commands are being entered in to the the Control Panel, the Modbus and digital input settings cannot be modified but may be displayed.

For pump control using Modbus or Fluidra Connect press the AUTO button for more than 3 seconds so that the pump goes into "REMOT" mode. In this mode, the pump will follow the commands sent by Fluidra Connect/Modbus and the HMI buttons will be disabled.

To quit "REMOT" mode and rerun the pump manually, press the AUTO button again for more than 3 seconds.

## 5. CONTROL PANEL ALARMS AND WARNINGS



The **Control Panel** will display Warnings and Alarms as "W \_\_" or "A \_\_" followed by two digits corresponding to the failure detected. In the event that there are several Warnings or Alarms, "M \_\_" (Multiple) will also be displayed.

Whenever an Alarm goes off, the pump will stop. However, if a Warning is displayed the pump can still be run.

To display **Warnings** and **Alarms**, enter the **EXPERT Mode** option in the **Settings Menu** (see Section 2.3.9).

When the battery (BA) alarm message appears on the HMI control screen, change the battery inside the controller as instructed below:

- 1- Disconnect the pump from the mains in order to work safely.
- 2- Remove the four screws from the HMI cover (no need to disassemble the cable connected to the terminal block).
- 3- Replace the CR2032 battery.
- 4- Reassemble the controller following the procedure the other way round.
- 5- Connect, disconnect and then reconnect the pump's mains power supply so that it resets and the BA message on the screen disappears.



## 6. HOW TO MOUNT THE CONTROL PANEL ON A WALL

The Victoria Plus Silent VS variable speed pump has a removable Control Panel that has also been designed to be mounted on walls.






Before starting, ensure that the pump is unplugged.





Unfasten the Control Panel from its base by exerting force sideways until it can be lifted upwards.

Disassemble the fastening base from the motor and mount it on a wall in the desired position.


Wire the Control Panel to its pump connection.

### Unplug the pump





## 7. DIAGRAM OF INVERTER WIRING



DIGITAL INPUTS					
K10	K11	K1	K12	Action	Mode
0	0	0	0	Change of mode	Before local
0	0	0	1	Pump off	Local
0	0	1	0	Low speed	Local
0	0	1	1	Pump off	Local
0	1	0	0	Medium Speed	Local
0	1	0	1	Pump off	Local
0	1	1	0	Medium Speed	Local
0	1	1	1	Pump off	Local
1	0	0	0	High speed	Local
1	0	0	1	Pump off	Local
1	0	1	0	High speed	Local
1	0	1	1	Pump off	Local
1	1	0	0	High speed	Local
1	1	0	1	Pump off	Local
1	1	1	0	High speed	Local
1	1	1	1	Pump off	Local

K4 Dry contact relay. Shows the pump's operating mode.

COM/NC Shows the pump is on. COM/NO Shows the pump is off.



Cod. 67547-0009/ Rev. 03

---

- We reserve the right to change all or part of the features of the articles or contents of this document, without prior notice.
  - Nous nous réservons le droit de modifier totalement ou en partie les caractéristiques de nos articles ou le contenu de ce document sans préavis.
  - Nos reservamos el derecho de cambiar total o parcialmente las características de nuestros artículos o contenido de este documento sin previo aviso.
  - Ci riserviamo il diritto di cambiare totalmente o parzialmente le caratteristiche tecniche dei nostri prodotti ed il contenuto di questo documento senza nessun preavviso.
  - Wir behalten uns das recht vor, die merkmale unserer produkte und den inhalt dieser beschreibung ohne vorherige unkündigung ganz oder teilweise zu ändern.
  - Reservamo-nos o direito de alterar na totalidade ou parcialmente as características dos nossos artigos ou o conteúdo deste documento sem aviso prévio.
  - Μπορούμε να αλλάξουμε εν όλω ή εν μέρει τα χαρακτηριστικά στα προϊόντα μας ή στο περιεχόμενο του παρόντος χωρίς προειδοποίηση.
- نحتفظ بالحق في تغيير كل أو جزء من ميزات المنتجات أو محتويات هذه الوثيقة بدون إشعار مسبق.