

QUICK GUIDE AND START-UP OF THE VICTORIA PLUS SILENT VS



ORIGINAL INSTRUCTIONS
INSTRUCTIONS D'ORIGINE
INSTRUCCIONES ORIGINALES
ISTRUZIONI ORIGINALI
ORIGINAL ANLEITUNG
INSTRUÇÕES ORIGINAIS
ΑΥΘΕΝΤΙΚΕΣ ΟΔΗΓΙΕΣ
الإرشادات الأصلية

SELF-PRIMING PUMP FOR SWIMMING POOLS

UK
CA

CE

ASTRALPOOL 

VICTORIA PLUS SILENT VS

English -

QUICK GUIDE AND START-UP OF THE VICTORIA PLUS SILENT VS 3

Français -

GUIDE RAPIDE DE MISE EN MARCHÉ DE LA POMPE VICTORIA PLUS SILENT VS 7

Español -

GUÍA RÁPIDA DE PUESTA EN MARCHA DE LA VICTORIA PLUS SILENT VS..... 11

Italiano -

GUIDA RAPIDA E AVVIAMENTO DEL VICTORIA PLUS SILENT VS..... 15

Deutsch -

KURZANLEITUNG UND INBETRIEBNAHME DES VICTORIA PLUS SILENT VS 19

Português -

GUÍA RÁPIDO DE COLOCAÇÃO EM FUNCIONAMENTO DA BOMBA VICTORIA PLUS SILENT VS.... 23


Ελληνικά -

ΓΡΗΓΟΡΟΣ ΟΔΗΓΟΣ ΚΑΙ ΕΚΚΙΝΗΣΗ ΤΟΥ VICTORIA PLUS SILENT VS 27

عربي -


31..... الدليل السريع والتقدم لـ VICTORIA PLUS SILENT VS

HYDRAULIC INSTALLATION.




If the pump has to be mounted on the ground. ____

ANCHOR DETAIL




Fitting the seals on the pump's outlets. ____

CORRECT




INCORRECT



Self-priming of the pump once connected to the hydraulic circuit. Fill the prefilter with water. ____




Closing the prefilter cover. ____



WIRING


Connect the pump's cable to the power line. Fit a residual current device (RCD) and a motor circuit breaker in the circuit.

Add the filter that is included with the pump.




230 V - 50 Hz
30 mA RCD
Motor circuit breaker adjusted to + 15% current marked in the pump nameplate.

CONTROL PANEL SET-UP




Sequence of the first start-up


Once the 2 minutes have elapsed, it will go into **STANDBY MODE**




Clock. Setting the time



DAY. DAY OF THE WEEK




Selection of the pump speed in **MANUAL** mode at a pre-set speed.




CONTROL PANEL SET-UP


Operating mode with manual speed setting



Savings display. Display of power savings



AUTO mode start-up



Setting auto mode

